



# EAD10

## Firmware Update Guide

EN

Thank you for choosing a Yamaha product.

This document explains how to update the firmware of the EAD10 and the update history.

### NOTICE

- Please save your important data onto the USB flash drive before updating the firmware of the EAD10.
- This updater is to be used at the user's own risk.
- DO NOT power off or disconnect the cable from the product during the updating process. The EAD10 may be damaged.
- DO NOT remove the USB flash drive from the product during the updating process. The EAD10 and the USB flash drive may become inoperable.
- If the update fails, and the EAD10 still does not operate correctly even after you execute the update once again, please contact your Yamaha dealer.
- This firmware and documentation are the exclusive copyrights of Yamaha Corporation.
- Reproducing or modifying all or parts of this firmware or its documentation without permission is strictly prohibited.
- The company names and product names in this document are the trademarks or registered trademarks of their respective companies.

## Included Files

---

This folder contains the following files:

- ead10\_en\_update\_guide\_v\*\*\*.pdf      This document (PDF file)
- the "\*\*\*.PGM" file      The update program

## Required Items

---

- USB flash drive formatted on the EAD10

Please check the URL below for a list of supported USB flash drives.


<http://download.yamaha.com>

After selecting your country and clicking on "Documents and Data" from the "Support" page, enter the model name into the search box.

## Checking the Current Version

---

Hold down the [RECORDER] button and then turn the power on by pressing the Standby/On switch.



"Firm ver : \*.\*\*\*" indicates the current version of the firmware.


If the message does not appear, turn the power off by pressing the Standby/On switch and try again.

# Updating Procedure

---

## NOTICE

**Please save your important data onto the USB flash drive before updating the firmware of the EAD10.**

1. After downloading, decompress the archived file, and then find the "\*\*\*\*.PGM" file. Copy the "\*\*\*\*.PGM" file to the root of the USB flash drive.
2. Make sure to turn the power off (the Standby/On switch is set to the Standby position,) and then connect the USB flash drive to the [USB TO DEVICE] terminal on the rear panel.
3. Hold down the [RECORDER] button, and then turn the power on by pressing the Standby/On switch.
4. Press the [  ] (Click) button to start the update process.  
This process takes a few minutes.
5. When the update process is completed, following message will appear.

EAD10 Updater  
Completed.  
Boot \*.\*.\* → \*.\*.\*  
Firm \*.\*.\* → \*.\*.\*  
Reboot.

6. Check the version of the firmware and you can turn the power off.

**This completes the update process.**

# Main Enhancements

---

## **v1.02 → v2.00**

- Continuous recording time when using a USB flash drive has been extended to 90 minutes.
- New Talkback function.
- New Pad function for switching Talkback on/off.
- New Noise Gate adjustment function.
- New Click Out routing function.
- Solved some minor problems.

## **v1.00 or v1.01 → v1.02**

- Improved the accuracy of the Click Tempo.
- Solved some minor problems.

Manual Development Group  
©2018 Yamaha Corporation  
Published 11/2019 YJ-B0