


RGX-420/S/-D6/DZ CONTROL SYSTEM




QC60980 0009
Printed in Taiwan




Selecting Pickups

[Pickup Selector]




(F1) (F2)



Front Pickup

(R1) (R2)



Rear Pickup

Pickup Selector Position	Effective Pickup Coil
1	F1 + F2 (Regular Humbucker)
2	F1 + F2 (Parallel Connected)
3	F1 + F2 + R1 + R2
4	F1 + R1
5	R1 + R2 (Regular Humbucker)



When the direct switch is on, the master volume, master tone and front pickup are completely bypassed. The result is rear humbucker only with full. This is regardless of the pickup selector position.

[Function of Direct Switch]