

## TOOLS for NUAGE V1.2.0 for Windows Release Notes

---

TOOLS for NUAGE V1.2.0 for Windows consists of the following programs.

- NUAGE Workgroup Manager V1.1.0
- NUAGE Extension V1.2.0
- NUAGE HARC Extension V1.0.0

### Contents

[System Component Compatibility](#)

[System Requirements for Software](#)

[Main Revisions and Enhancements](#)

[Update History](#)

### System Component Compatibility

Please make sure to use the appropriate versions of NUAGE system components which are compatible with each other, referring to the following website. Using an unsupported component combination may result in malfunction.

[http://www.yamahaproaudio.com/global/en/products/daw\\_systems/nuage/downloads.jsp](http://www.yamahaproaudio.com/global/en/products/daw_systems/nuage/downloads.jsp)

### System Requirements for Software

#### NOTE

Note that the system requirements may be slightly different from those described below depending on the particular operating system.

OS	Windows 7 SP1, Windows 8/8.1
CPU	Intel/AMD dual core processor
Memory	2GB or more
Interface	Equipped with an Ethernet connector Equipped with an RS-232C connector for controlling an AD8HR from the Nuage Fader. (When connecting the AD8HR to the USB connector, make sure to use a USB to Serial converter.)
Hard Disk	Free disk space of 100MB or more; high-speed hard disk
Others	Nuendo 6.0.4 or later, Cubase 7.0.4 or later

## **Main Revisions and Enhancements**

### **V1.1.0 → V1.2.0**

#### **New Functions**

- Added support for remote operation of AD8HR remote preamp from Nuage Master.
- Improved the EQ Band Curve display.
- Added support for marker colors in Nuendo.
- Improved parameter indications on the Multi Function Display.
- Improved pan control operations from the channel strip.

#### **Fixed Bugs**

- Solved a problem in which the cue mix monitor would be interrupted when changing the Monitor from the CONTROL ROOM section on the Nuage Master.
- Solved a problem in which the Select Track pop-up window of the DAW A may have been displayed when DAW B or DAW C was operated by using NUMERIC PAD.
- Solved a problem in which direct monitoring would be disabled if executing "Revert" of the Nuendo when direct monitoring is on.
- Solved a problem in which [MOVE] would become dim if pressing and holding [ZOOM] when [MOVE] and [SELECT] on the Nuage Master are lit.
- Solved a problem in which no plug-in effect may have been applied if the order of the effects were rearranged when the Channel Strip rack in "Mixer" on Nuendo was displayed.
- Solved some other minor problems.

## **Update History**

### **V1.0.0 → V1.1.0**

#### **New Functions**

- Added the ADR mode.
- Added the functions for configuring the buttons in the USER ASSIGNABLE section.
- Added support for remote operation of the AD8HR remote preamp.
- Added the display in the [Channel name display].
- Added display channels on the LCD.
- Added some track select operations.
- Added some Zoom In and Zoom Out operations.
- Added some editing operations.
- Added the input format when you set the Project Cursor position in the Locate function.

- The dynamics of each channel can now be operated on the DYN page of Nuage Master
- Added the function for locking/unlocking “TEMPO” and “CLICK” in the MAIN page of the TRANSPORT page of Nuage Master.
- Key input can now be executed continuously while pressing the [Input keys] in the NUMERIC PAD section of the Nuage Master.
- Added the display of “Channel Configuration” to “Channel Information” in the upper left of the CHANNEL CONTOROL page of the Nuage Master.
- Added the “L&R” parameter, which lets you simultaneously operate “PAN” of both left and right channels, to the PAN page of Nuage Master.
- Changed so that only applicable channel strip types are displayed when “Show One Channel Strip Type” is selected in the “Mixer” window of Nuendo.
- Changed the display of [Channel name display] in the Left Lock area or the Right Lock area.

The other main fixes and enhancements for each program are explained below.

### **NUAGE Workgroup Manager**

V1.0.0 → V1.1.0

- Changed the "Check for Update" button to the "Update" button.

---

Company and product names that appear in this document are the trademarks or registered trademarks of their respective companies.

(C) 2013-2014 Yamaha Corporation.

## TOOLS for NUAGE V1.2.0 for Windows リリースノート

---

TOOLS for NUAGE V1.2.0 for Windows は、以下のプログラムで構成されています。

- NUAGE Workgroup Manager V1.1.0
- NUAGE Extension V1.2.0
- NUAGE HARC Extension V1.0.0

### 目次

[NUAGE システムコンポーネントの互換性](#)

[ソフトウェアの動作環境](#)

[主なアップデートの内容](#)

[更新履歴](#)

### NUAGE システムコンポーネントの互換性

NUAGE システム製品は、下記のウェブサイトを参照して互換性のあるバージョンをお使いください。互換性の無いバージョンを組み合わせで使った場合、誤動作の原因になることがあります。

[http://www.yamahaproaudio.com/japan/ja/products/daw\\_systems/nuage/downloads.jsp](http://www.yamahaproaudio.com/japan/ja/products/daw_systems/nuage/downloads.jsp)

### ソフトウェアの動作環境

#### NOTE

お使いの OS によっては、下記の仕様以上の条件を満たす必要があります。

OS	Windows 7 SP1, Windows 8/8.1
CPU	Intel/AMD デュアルコアプロセッサ
メモリー	2GB 以上
インターフェース	・イーサネット端子を搭載していること ・AD8HR をリモートコントロールする場合、RS-232C 端子または USB 端子を搭載していること(AD8HR を USB 端子に接続する場合、シリアル-USB 変換コネクタが必要)
ハードディスク	100MB 以上の空き容量、高速なハードディスク
その他	Nuendo 6.0.4 以降、Cubase 7.0.4 以降

## 主なアップデートの内容

### V1.1.0 → V1.2.0

#### 新機能

- Nuage Master からの AD8HR リモートコントロールに対応しました。
- EQ バンドカーブの表示に対応しました。
- Nuendo のマーカーカラーに対応しました。
- マルチファンクションディスプレイ上のパラメーター表示を改善しました。
- チャンネルストリップからのパンコントロールを改善しました。

#### 修正された不具合

- Nuage Master の CONTROL ROOM セクションで「モニター」を切り替えたとき、キューミックスのモニターが一時的に途切れてしまう不具合を修正しました。
- DAW B または DAW C を NUMERIC PAD で操作したとき、DAW A のトラック選択機能のポップアップが表示されることがある不具合を修正しました。
- ダイレクトモニタリング中に Nuendo の「最後に保存した状態に戻す」を実行すると、ダイレクトモニタリングが無効になる不具合を修正しました。
- Nuage Master の[MOVE]と[SELECT]が点灯しているとき、[ZOOM]を長押しすると[MOVE]が暗点灯する不具合を修正しました。
- Nuendo の「ミキサー」で「チャンネルストリップ」ラックを表示しているとき、エフェクトの順番を入れ替えると、エフェクトが無効になることがある不具合を修正しました。
- その他の軽微な不具合を修正しました。

## 更新履歴

### V1.0.0 → V1.1.0

#### 新機能

- ADR モードを追加しました。
- USER ASSIGNABLE セクションへの機能の割り当てを追加しました。
- AD8HR のリモートコントロールに対応しました。
- [チャンネルネームディスプレイ]の表示機能を追加しました。
- チャンネルの表示機能を追加しました。
- トラックの選択方法を追加しました。
- ズームに関する操作を追加しました。
- 編集に関する操作を追加しました。
- ロケート機能で「プロジェクトカーソル」の位置を入力するときの入力方法を追加しました。

- Nuage Master の DYN ページで各チャンネルのダイナミクスを操作できるように変更しました。
- Nuage Master の TRANSPORT ページの MAIN ページに「CLICK」と「TEMPO」をロック/アンロックする機能を追加しました。
- Nuage Master の NUMERIC PAD セクションで[入力キー]を押し続けると、連続で入力するように修正しました。
- Nuage Master の CHANNEL CONTROL ページの画面左上にある「チャンネル情報」に「チャンネル構成」の表示を追加しました。
- Nuage Master の PAN ページに左右のチャンネルの「パン」を同時に操作する「L&R」パラメーターを追加しました。
- Nuendo のミキサー画面で「1 つのチャンネルストリップタイプを表示」オプションが選択されているとき、該当するチャンネルストリップタイプだけが表示されるように変更しました。
- レフトロックエリアまたはライトロックエリアにあるときのチャンネルの[チャンネルネームディスプレイ]の表示を変更しました。

その他の主なアップデート内容については、以下にプログラム別で説明します。

#### **NUAGE Workgroup Manager**

V1.0.0 → V1.1.0

- 「Check for Update」ボタンを「Update」ボタンに変更しました。

---

本文に掲載されている会社名および商品名等は、各社の登録商標または商標です。

(C) 2013-2014 Yamaha Corporation.